



**Frequently Asked Questions:**

- Q. I have lots of leds lit on the signal finder and yet my TV reception is not good on all channels.
- Try switching your booster to low / normal, and continue to rotate the aerial until the next maximum peak. If you do not have the facility to switch your booster, try fitting the Signal Finder between the aerial and the booster.
  - If your aerial is horizontal, try adjusting so that it is vertically polarized (or vice versa).
- Q. How to I check the battery on my Signal Finder?
- As long as the green power LED shows brightly, the battery is good.
- Q. Can I use the Pro TV & Sat Signal finder in line with my aerial and receiver?
- The Pro TV & Sat Signal finder cannot be used in line, simply plug your TV aerial into the Signal Finder, align your aerial then re-fit the lead to the TV.
- Q. How can I find out the Elevation angle for my satellite dish for my location?
- The Internet is a good source of such information, but as a rough guide for the UK and Astra2 (Sky Digital), use the angle from the following list that is nearest to your location. Please note that the angle is from horizontal and you should make allowance if your dish is not referenced to level ground or a vertical surface. The further south the greater the angle, for example, if you are south of London, use 25deg.
- |                        |                                 |                       |
|------------------------|---------------------------------|-----------------------|
| London..... 24-25deg   | Manchester / Cork..... 21-22deg | Aberdeen... 18-19deg  |
| Cardiff..... 23-24deg  | Newcastle / Dublin.... 20-21deg | Inverness... 17-18deg |
| Birmingham... 22-23deg | Edinburgh / Belfast... 19-20deg | Orkney..... 16-17deg  |
- Q. How do I adjust the elevation angle on my satellite dish?
- The elevation angle is how high into the sky, the dish is directed. All dishes are different, but most have some way of indicating the rough elevation angle and a means of screw / nut locking for the mechanism. There should be an indicated guide in degrees. Please remember that this relies on the dish being mounted either level or on a perfectly vertical pole.
- Q. My Signal Finder doesn't automatically power up when I connect it to my satellite dish/receiver.
- The automatic power function relies on a sound cable connection between the receiver, Signal Finder and LNB. Please check that the cable is not damaged or faulty and that the receiver is switched on and not in standby.

©Fringe Electronics Ltd 2009

# PRO TV & SATELLITE SIGNAL FINDER

